

Kia Ceed 1.6T 204HP

1. Remove air filter housing.
2. Find plugs for intake pressure sensors. Disconnect them and connect box adapters between.



3. If box is equipped with yellow-red wire connect it to positive terminal in an engine compartment.