


## Nissan Qashqai 1.6T 163HP

1. Find plugs for intake pressure sensors. Disconnect them and connect box adapters between.



2. If box is equipped with yellow-red wire connect it to positive terminal in an engine compartment.